



## CCAD's Block Library Instructions

Blocks from the library can be placed into a drawing in several ways.

1. Copy and paste a block from the library dwg file to your dwg.
2. Insert the library dwg file into your current dwg. Use the Browse button in INSERT command window or Block Palette (2020+) to place the desired block.
3. Use the DesignCenter palette to load, view and insert the blocks from the library dwg file.
4. Create a Tool Palette
  - a. Locate the library dwg file using the DesignCenter palette.
  - b. Right-click on the library dwg and select Create Tool Palette.

Many of the blocks include WIPEOUTS to eliminate trimming of overlapping objects. The WIPEOUT frame display is controlled by the FRAME setting:

- 0 = not visible or plotted
- 1 = visible and plotted
- 2 = visible, but not plotted

Use the DRAWORDER command bring the blocks to the FRONT or send objects to the BACK if needed.

Watch the instructional [video](#) that demonstrates the above options.